# Feature operation

| | | | |
|---|---|---|---|
| **AutoDial** | | | |
| Store | AutoDial | | ▶ AutoDial |
| Use | | AutoDial | |
| Display | Display | AutoDial | |
| **Call Forward** | | | |
| Activate | Fwd | | ▶ Fwd |
| Deactivate | ▶ Fwd | | |
| Reinstate | Fwd | ▶ Fwd | |
| View number | Display | ▶ Fwd | |
| **Call Pickup** | | Pickup | |
| **Call Waiting** | | | |
| Answer | | ▶ CallWait | |
| Return to first call | | | |
| **Conference** | Conf | | ▶ Conf |
| **Handsfree** | | | |
| Activate | | Line key | |
| Switch to handset | | | |
| Handset to handsfree | | | |
| **Hold** | | **Off Hold** | |
| Place a call on hold | | Take a call off hold | Line key |
| **Last Number Redial** | | Line key | |
| **Message** | | Inbox | |
| **Ring Again** | | | |
| Activate | RngAgn | | |
| When notified | | ▶ RngAgn | |
| Deactivate | ▶ RngAgn | | |
| **Shift** | Outbox | | |
| **Transfer** | Trans | | ▶ Trans |

# Icon Legend

| Icon | Description or Action |
|---|---|
| | A lock on the display indicates an encrypted call. |
| | Lift the handset, press the DN key, or press the **Handset** key. |
| | Replace the handset, or press to end the call. |
| | Dial a number. |
| Line key | Tap the line (DN) icon. |
| ▶ AutoDial | The ▶ flashes when a feature is being programmed.<br>The ▶ is steady when a feature is active. |
| Services | Tap the **Services** icon. |
| Inbox | Tap the **Message** icon. |
| | Press the **Navigation** keys. |
| | Press the **Handsfree** key. |
| | Press the **Mute** (on/off) key. |
| Directory | Tap the **Directory** icon. |

# Services and telephone options menu

| | | | | |
|---|---|---|---|---|
| **Services menu** | | | | |
| Services | | Select | | |
| **Telephone Options menu** | | | | |
| **Volume adjustment** | | | | |
| Ringer | Select | | Select | Services |
| Handset listen | Select | | Select | Services |
| Handsfree Listen | Select | | Select | Services |
| Headset listen | Select | | Select | Services |
| Buzzer | Select | | Select | Services |
| **Contrast adjustment** | | | | |
| | Select | | Select Cancel | Services |
| **Language** | | | | |
| | Select | | Select | Services |
| **Date/Time** | | | | |
| | Select | | Select Cancel | Services |
| **Local dialpad tone** | | | | |
| | Select | | Select Cancel | Services |
| **Ring type** | | | | |
| | Select | | Select Play Cancel | Services |
| **On hook default path** | | | | |
| | Select | | Select Cancel | Services |
| **Live dialpad** | | | | |
| | Select | Turn On or Off | Select Cancel | Services |

For more information on using your Avaya 2007 IP Deskphone, see the *Avaya 2007 IP Deskphone User Guide* (NN43118-100).

## Tools/Navigation soft keys

| | |
|---|---|
| | Tap this icon to determine which external applications are registered (for example, My CallPilot), and launch them by tapping on the appropriate icon. |
| | Tap this icon to access the **Telephone** screen. |
| | Tap this icon to go to the primary external application. The icon of the application is displayed. |
| | Tap this icon to access the tools used on the Avaya 2007 IP Deskphone. |
| | Tap this icon to display a virtual keyboard (pop-up keyboard) for text entry. |

## Avaya 2007 IP Deskphone

AVAYA

# Avaya 2007 IP Deskphone

For Avaya Communication Server 1000

## Quick Reference Card

Date: November 2010
Document Release: Standard 04.01
Document Number: NN43118-101
Copyright © 2010 Avaya Inc.
All rights reserved.